



FIGURE 9 - II



THE CONTRACTOR, AT HIS OPTION, MAY USE ENDS OF PRECAST BOX AT 90° SKEW WITH OPTIONAL LENGTH AS SHOWN. ANY ADDITIONAL COST DUE TO THE USE OF THE OPTION WILL BE PAID FOR BY THE CONTRACTOR.


ANGLES "A" AND "B" SHALL BE MAINTAINED.



THE CONTRACTOR, AT HIS OPTION, MAY USE ENDS OF PRECAST BOX AT 90° SKEW WITH OPTIONAL LENGTH AS SHOWN. ANY ADDITIONAL COST DUE TO THE USE OF THE OPTION WILL BE PAID FOR BY THE CONTRACTOR.


ANGLES "A" AND "B" SHALL BE MAINTAINED.

FIGURE 9 - II M



THE CONTRACTOR, AT HIS OPTION, MAY USE ENDS OF PRECAST BOX AT 90° SKEW WITH OPTIONAL LENGTH AS SHOWN. ANY ADDITIONAL COST DUE TO THE USE OF THE OPTION WILL BE PAID FOR BY THE CONTRACTOR.

ANGLES "A" AND "B" SHALL BE MAINTAINED.



THE CONTRACTOR, AT HIS OPTION, MAY USE ENDS OF PRECAST BOX AT 90° SKEW WITH OPTIONAL LENGTH AS SHOWN. ANY ADDITIONAL COST DUE TO THE USE OF THE OPTION WILL BE PAID FOR BY THE CONTRACTOR.

ANGLES "A" AND "B" SHALL BE MAINTAINED.